

# SmartFlick 10000 mAh Power Bank (22.5W) - User Manual

## 1. Introduction

Thank you for purchasing the SmartFlick 10000 mAh Power Bank. This power bank supports fast charging with multiple input and output options, ensuring your devices stay powered up wherever you go. Please read this manual thoroughly before using the product.

## 2. Package Contents

- 1 x SmartFlick 10000 mAh Power Bank
- 1 x USB-C to USB-A Cable
- 1 x Warranty Card (1-year warranty)

## 3. Specifications

- Model:-PBS-01
- Capacity: 10000 mAh / 37Wh
- Input Ports:
  - USB-C: 5V/3A, 9V/2A, 12V/1.5A (Max 18W)
  - Micro USB: 5V/3A, 9V/2A (Max 18W)
- Output Ports:
  - USB-C : 5V/3A, 9V/2.22A, 12V/1.67A, 5-11V/2A PPS 22W (Max 22.5W)
  - USB-A : 5V/3A, 9V/2A, 10V/2.25A, 12V/1.5A (Max 22.5W)
  - Technology: Quick Charge 3.0, PD (Power Delivery), PPS (Programmable Power Supply)
    - Compatibility: Smartphones, tablets, Bluetooth devices, and other USB-powered devices
    - Safety Features: Over-current, over-voltage, short-circuit, over-discharge, and over-temperature protection

## 4. Product Overview

- Front View:
- USB-A Port (QC 3.0 supported)
- USB-C Port (PD/PPS supported)
- LED battery indicator
- Side View:
- Micro USB Input
- USB-C Input/Output

## 5. Instructions for Use

### 1. Charging the Power Bank:

- Use either the Micro USB or USB-C port to charge the power bank.
- Connect the input port to a compatible charger (not included).
- The LED indicator lights will blink to show charging status and will turn solid when fully charged.

### 2. Charging Your Devices:

- Connect your device to the USB-A or USB-C output port using a compatible cable.
- The power bank will automatically begin charging the device.
- For fast charging, ensure your device supports QC, PD, or PPS technology.

### 3. Battery Level Check:

- Press the power button on the side to check the battery level.

The LED lights indicate the remaining power:

- 4 LEDs: 75-100%
- 3 LEDs: 50-75%
- 2 LEDs: 25-50%
- 1 LED: 0-25%

### 4. Safety Note:

- Avoid exposing the power bank to water or extreme temperatures.
- Do not charge and discharge simultaneously to maintain battery health.

## 6. Safety and Maintenance

- Avoid disassembling or modifying the power bank.
- Keep the power bank in a dry environment and do not expose it to temperatures above 45°C or below 0°C.
  - Recharge the power bank every 3 months when not in use to maintain battery performance.
  - Keep the power bank away from children and pets.

## 7. Troubleshooting

### Issue Solution

Power bank not charging Ensure the cable and charger are properly connected. Try a different cable or power source if necessary.

Device not charging Check if the cable is securely connected and compatible with the device.

Slow charging Confirm the device supports fast charging technology (QC, PD, or PPS).

LED indicator not working Reset the power bank by disconnecting all devices and trying a different charger.

## 8. Warranty Information

This product comes with a 6-Month limited warranty. For any issues or queries, contact SmartFlick customer support at [support@smartflick.in](mailto:support@smartflick.in).

## 9. Contact Information

For support, product details, or warranty assistance:

- Email: [support@smartflick.in](mailto:support@smartflick.in)
- Website: [www.smartflick.in](http://www.smartflick.in)

Thank you for choosing SmartFlick!